

## Design Equations

---

### Batch Reactor

$$\frac{d(V_R c_j)}{dt} = \sum_i^{n_{rxns}} \nu_{ij} r_i V_R$$

$$\frac{dT}{dt} = \frac{UA(T_a - T) - \sum_i^{n_{rxns}} r_i \Delta H_{Ri} V_R}{V_R \sum_j^{n_{components}} c_j \bar{C}_{pj}}$$

### Plug Flow Reactor

$$\frac{d(Qc_j)}{dV} = \sum_i^{n_{rxns}} \nu_{ij} r_i$$

$$\frac{dT}{dV} = \frac{\frac{2}{R}U(T_a - T) - \sum_i^{n_{rxns}} r_i \Delta H_{Ri}}{Q \sum_j^{n_{components}} c_j \bar{C}_{pj}}$$

### Stirred Tank Reactor

$$\frac{d(V_R c_j)}{dt} = Q_f c_{jf} - Q c_j + \sum_i^{n_{rxns}} \nu_{ij} r_i V_R$$

$$\frac{dT}{dt} = \frac{UA(T_a - T) - \sum_i^{n_{rxns}} r_i \Delta H_{Ri} V_R + Q_f \sum_j^{n_{components}} c_{jf} (\bar{H}_{jf} - \bar{H}_j)}{V_R \sum_j^{n_{components}} c_j \bar{C}_{pj}}$$

### Steady-state Continuous Stirred Tank Reactor (constant phase)

$$0 = Q_f c_{jf} - Q c_j + \sum_i^{n_{rxns}} \nu_{ij} r_i V_R$$

$$0 = UA(T_a - T) - \sum_i^{n_{rxns}} r_i \Delta H_{Ri} V_R + \sum_j^{n_{components}} Q_f c_{jf} \int_T^{T_f} \bar{C}_{pj} dT$$